# IP Speaker

IS-640 User manual





# [Content]

1.Introduction	1
2.Parts list:	1
3.Panel description	2
4.Web Page Setting	3
5 Network	5
5.1 Network Status5.2 WAN Setting	
6. SIP Setting	
6.1 Service Domain	6
6.2 Port Setting	7
6.3 Codec Setting	7
6.4 Audio Setting	8
6.5 Other Setting	9
7.STUN Setting	9
8.Update	10
8.1 New Firmware	10
8.2 Default Setting	12
9.System Authority	13
10.Save Change	13
11.Reboot	14

## 1.Introduction

IS-640 IP Speaker provide a user-friendly control and simple voice broadcasting. The product is designed to provide easy use for any office, department store, factory, school to be able to quickly broadcast announcements to their any assigned office or branch or classes (or a group of office or branch or classes).

## 2.Parts list:

#### 2.1. IP Speaker(IS-640) main body



2.2. Network cable 2M




2.3. AC power cord 1.8M



2.4.User manual

# 3.Panel description



3.1 IP Reset Button: please press the button in 7-8 seconds till the status led flash blink to restore the factory default IP 192.168.0.100

#### 3.2 Status:

1. light turn off : standby

2. light turn on : call in status

3. light twinkle: user is speaking

#### 3.3 Power:

1. light turn off : no power

2. light turn on : standby

3.4 LAN: Standard RJ-45 socket, connecting to Hub circuit

3.5 AC 100~240V : power socket

# 4. Web Page Setting

- Step 1: Browse the IP address <a href="http://192.168.0.100">http://192.168.0.100</a> from Internet Explorer
- Step 2: Please enter the username and password for authentication. (default username: voip , Password: 1234). The page follows when the username and password are correct



Step 3: When you login the web page, you can see current System Information like Model Name, Firmware Version, Codec, Version ....etc in this page.



#### IS-640 v1.130

Module Description:	IP Speaker for LAN Vocal PA System,
Firmware Version:	Fri Apr 10 11:27:41 2015.
Codec Version:	Thu Jul 29 11:15:45 2010.
Contact Address:	150, Shiang-Shung N.Road., Taichung, Taiwan, R.O.C
Tel:	886-4-23058000
Fax:	886-4-23022596
E-Mail:	sales@portech.com.tw
Web Site:	http://www.portech.com.tw.

© 2014 PORTech Communications Inc.

You also can see the function lists in the left side Include Network ,SIP Setting,STUN Settings, Update,System Authority,Save Change , Reboot .



#### IS-640 v1.130

Module Description:	IP Speaker for LAN Vocal PA System,	
Firmware Version:	Fri Apr 10 11:27:41 2015.	
Codec Version:	Thu Jul 29 11:15:45 2010.	
Contact Address:	150, Shiang-Shung N.Road., Taichung, Taiwan, R.O.C	
Tel:	886-4-23058000	
Fax:	886-4-23022596	
E-Mail:	sales@portech.com.tw	
Web Site:	http://www.portech.com.tw.	

© 2014 PORTech Communications Inc.

- 4.1.Network: provide Status, WAN Setting
- 4.2.SIP Settings: Provide Service Domain Port Setting (SIP and RTP port setting), Code Setting, Audio Setting, Other Setting
- 4.3.STUN Setting: provide STUN Setting to penetrate the Firewal •
- 4.4.Update : provide New Firmware (firmware upgrade), Default Settings (restpre default setting).
- 4.5. System Authority: provide user to change login name and password.
- 4.6. Save Change: Save the changes you have done
- 4.7.Reboot :Restart the system. •

## 5 Network


#### 5.1 Network Status

Network Status: you can check the current Network Setting in this page

#### **Net Status**

Master	WAN Interface	LAN Interface
Туре	Fixed IP Client	
IP	192.168.0.100	-
Mask	255.255.255.0	15
Gateway	192.168.0.254	12
MAC	00037E014E67	-

#### 5.2 WAN Setting



- (1) The TCP/IP Configuration item is to setup the WAN port's network environment. You may refer to your current network environment to configure the system properly.
- (2) The PPPoE Configuration item is to setup the PPPoE Username and Password. If you have the PPPoE account from your Service Provider, please input the Username and the Password correctly.
- (3) When you finished the setting, please click the Submit button.


# 6. SIP Setting

#### 6.1 Service Domain

In Service Domain Function you need to input the account and the related informations in this page, please refer to your ISP Provider. You can register three SIP accounts.



#### Service Domain Settings




field	explain
Realm 1 (Default)	
Active	Default:Off , on: active this account
Display Name	you can input the name you want to display
User Name	you need to input the User Name get from your ISP.
Register Name	you need to input the Register Name get from your ISP.
Register Password	you need to input the Register Password get from ISP.
Domain Server	you need to input the Domain Server get from your ISP.
Proxy Server	you need to input the Proxy Server get from your ISP
Outbound Proxy	you need to input the Outbound Proxy get from your ISP. If
	your ISP does not provide the information, then you can
	skip this item.
Status	You can see the Register Status. Not Register(register
	fail) , Register(register successful) 。

When you finished the setting, please click the Submit button. Remember to click "Save Charge"


#### 6.2 Port Setting

You can setup the SIP and RTP port number in this page. Each ISP provider will have different SIP/RTPport setting, please refer to the ISP to setup the port number correctly. When you finished the setting, please click the Submit button and "Save Charge"



#### 6.3 Codec Setting


You can setup the Codec priority, RTP packet length in this page. You need to follow the ISP suggestion to setup these items. When you finished the setting, please click the Submit button and "Save Charge".



#### 6.4 Audio Setting

Set speaker volume and voice detect function





Field	description
Speaker Volume	Default :50,maximum: 64 , minimum: 0.
Detection Sensitivity	Default:32,maximum: 32, minimum: 0
Send Detected	Default:OFF;ON:send Voice detection packet,OFF:don't
	send Voice detection packet.
Send Destination	Send IP Address for sending Voice detection packet.

When you finished the setting, please click the Submit button and "Save Charge".


#### 6.5 Other Setting



SIP Expire Time: Default:60; set register's time interval ;range:30~86400 sec When you finished the setting, please click the Submit button and "Save Charge".

# 7.STUN Setting

you can setup the STUN Enable/Disable and STUN Server IP address in this page. This function can help your VoIP device working properly behind NAT. To change these settings please following your ISP information. When you finished the setting, please click the Submit button.




9

# 8.Update

In Update you can update the system's firmware to the new one or execute the factory reset to let the system back to default setting.

#### 8.1 New Firmware




Field	Description
Code Type	Default:Risc (.gz). Provide Risc (system firmware.gz) and DSP
	(DSP firmware.ds).
File Location	Click the "Browse" button in the right side of the File Location or
	you can type the correct path and the filename in File Location
	blank.

Setep 1: choose Updte → New Firmware, choose Code Type: Risc and click the "Browse" button in the right side of the File Location or you can type the correct path and the filename in File Location blank.

## Update Firmware




Setep 2:choose [gz] file ,then click [open].




Setep 3:[File Location] will show the file location and file name. after confirm ,please click submit

## Update Firmware



Setep 4: please don't turn power off when system updating. It is important. The updating time is about 3 minutes.

## Note Information



Setep 5: After finished update firmware, please click Refresh (F5), then you can set other settings

#### 8.2 Default Setting

In this page: Update/ Default Settings, you could restore the factory default settings to the system. All setting will restore default setting.

IP will retain original IP as usual not default IP.



Step1: choose Update→Default Setting. When you want to restore default setting, please click [Restore]. You can clear all settings and auto refresh as follows.

## Restore Default Settings

Restore default settings: default

Setep 2:please wait for a moment while rebooting as follws.

### Note Information

Booting
Please wait for a moment while rebooting ...

Setep 3: After reboot, webpage will be back to main page. Please click refresh(F5) ,then you can set other settings

# 9.System Authority



In System Authority you can change your login name and password.

When you finished the setting, please click the Submit button and "Save Charge".

# 10.Save Change


In Save Change you can save the changes you have done. If you want to use new setting in the VoIP system, you have to click the Save button. After you click the Save button, the system will automatically restart and the new setting will effect.



## 11.Reboot

Reboot function you can restart the system. If you want to restart the system, you can just click the Reboot button, then the system will automatically.






Reboot system: Reboot

Please don't turn power off while rebooting, thanks

## **Note Information**



After reboot, webpage will be back to main page. Please click refresh(F5) ,then you can set other settings